

FROMENTAL

INSTALLATION GUIDE CARTONNAGE & WAXED PAPER WALLCOVERINGS

Fromental wallcoverings are different in construction from most everyday wallcoverings. Our Cartonnage & Waxed Paper wallcoverings are backed with a non-woven paper backing.

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND DO NOT START HANGING UNLESS YOU ARE CERTAIN YOU HAVE UNDERSTOOD THE DIRECTIONS.

IF IN ANY DOUBT, PLEASE CALL FROMENTAL TO CLARIFY PRIOR TO INSTALLATION. THIS IS A LUXURY PRODUCT AND CAN EASILY BE RUINED DURING INSTALLATION.

WE RECOMMEND USING ONLY FROMENTAL APPROVED INSTALLERS. WE WILL NOT ACCEPT RESPONSIBILITY FOR HANGING FAULTS.

IMPORTANT NOTE:

Each individual panel should be reviewed and approved by the client prior to installation. If during installation there is any concern regarding the product, please **stop immediately** and contact Fromental. Most problems can be corrected if the panels are returned prior to installation. We recommend installing 2-3 panels for client approval before commencing with full installation.

Once panels are installed, problems may only be fixed by sending a Fromental artist to site and this can incur significant costs.

All orders (except for Plains) are supplied with either a Fromental miniature or a panel plan. The Fromental miniature shows the layout of the design within the elevation of the wall/room and the position of each panel. A panel plan shows the optimal panel placement within the room/wall. If for some reason this has not been included, please contact Fromental immediately.

WALL PREPARATION:

It is essential that walls are correctly prepared, walls should be clean, dust free, smooth, and sound and checked for faults; Any faults should be repaired. The quality of the wall may be a factor for possible reactions, causing discoloration, shrinkage of the wallcovering or it may become detached from the wall.

Walls then need to be sized with an appropriate size. Most size is PVA based, and this can be used at various dilutions. The more absorbent the wall, the thinner the size.

The walls need to be lined with thousand grade lining paper (UK: 1000 grade lining paper / acid free blank stock USA: BLANK STOCK liner).

Wall surface / lining paper should be clean and white. Lining can be installed either vertically or horizontally (USA Railroad lining). All surrounding paintwork should be completed prior to lining.

ROOM CONDITIONS: The wallcovering should be stored within the area it will be installed for at least 3 days prior to installation. The room conditions should be kept the same before, during and for at least 3 days after installation.

ADHESIVE:

- A thick ready mixed traditional modified starch 'tub paste' should be used. (UK - Murabond 'black top', Albany Yellow top, USA -Roman 234). Stir well and do not dilute the paste!

www.fromental.co.uk

Ground floor, 2 Kimberley Road, London NW6 7SG

t: +44 208 960 8899 f: +44 207 681 2343 e: info@fromental.co.uk

FROMENTAL

TRIMMING:

- For best installation, panels should be DRY TRIMMED on site by hand before paste is applied, this should ensure a clean seam.
- Edges should be trimmed with a sharp blade; blades should be changed often.
- The panels have trim on the right-hand side, this will be marked by either a small pencil mark as a guide on the back of the panel (normally 15mm or ½") or noted with a guide on the front of a panel (25mm or 1")
- This should be cut down on the table using a knife and straight edge or traditional wallpaper trimming tool before the paper is pasted.

If panels have been supplied pre-trimmed these should be placed side by side to gauge exact panel match.

Note: Our Artists work very hard to make the design match accurately however as with any hand-painted product mismatches are inevitable but should only be very minor. On some more painterly areas it is impossible to make all brushstrokes continue exactly and some slight variation is natural and should be expected.

If when checking the panels before trimming and installation you find significant design mismatch, please contact us immediately. Any serious mismatch is easier to correct in our studios prior to installation rather than once the panels are on the wall.

MATCHING DESIGN TO FROMENTAL MINIATURE:

- Panels are numbered to match the Fromental miniature which will be supplied in most cases. These miniatures show where each panel should fit within the room layout. We strongly recommend installers check through all panels before installation.

DRY-HANG or PASTE-THE-WALL METHOD:

- The paper should be laid face down on clean table. The back of the paper should be wet with a sponge and allowed to soak for 1-2 minutes to become supple before hanging. IMPORTANT NOTE: Avoid getting any moisture on the face of the panel.
- A thick layer of paste should be applied evenly to the wall with brush or roller.
- Starting at the top of the wall apply the panel to the wall.
- The panel joins should be very tight (close butted) to allow for any minor shrinkage, which may occur during drying. The paper does not swell or stretch due to the non-woven backing, so seams must be pushed together immediately as each drop is placed on the wall.
- Once on the wall, the panels can be pushed into position and flattened using a spatula or seam-roller.

Great care should be taken to avoid getting paste onto the surface of the wallcovering. Our cartonnage and waxed papers are hand-painted/hand-finished with water-based paints and as such cannot be wiped with a wet or damp cloth, use a dry cloth only.

Tip: Remember to shield the paper with a caulking tool when removing any paste from the skirting or ceilings.

Please note our cartonnage papers are hand-painted, using colours mixed by hand, as such there may be some minor colour variation between samples and final orders. There may occasionally be slight colour variation from panel to panel within a set due to the hand-made nature of the product.

www.fromental.co.uk

Ground floor, 2 Kimberley Road, London NW6 7SG

t: +44 208 960 8899 f: +44 207 681 2343 e: info@fromental.co.uk